

4WD LEAF SPRINGS

MAKE AND MODEL	FRONT			REAR		
	STD Height	Raised Height	EHD Height	STD Height	Raised Height	EHD Raised
DAIHATSU						
FEROZA	ADJUSTABLE TORSION BAR				DIA-004	DIA-002
ROCKY SWB F70, LWB F75 DIESEL		DIA-001*	DIA-017*		DIA-004	DIA-002
ROCKY SWB F80, LWB F85 PETROL		DIA-003*	DIA-001*		DIA-004	DIA-002
ROCKY T/BACK F77 DIESEL		DIA-001*	DIA-017*		DIA-007	DIA-008
ROCKY T/BACK F87 PETROL		DIA-003*	DIA-001*		DIA-007	DIA-008
* EXCEPT WIDE TRACK						
FORD						
COURIER PC PD PG PH						MAZ-005
EXPLORER UN UP UQ US					FOR-028	
MAVERICK TRAYBACK		TOY-059*	TOY-060*		NIS-015	NIS-016**
RANGER 2007 TO 2011					MAZ-009	MAZ-009HD
RANGER 2012					MAZ-010**	MAZ-010HD**
RANGER 2012 *TOP STAGE ONLY*					MAZ-010ST** +	MAZ-010HDTS** +
* 35MM L/CRUISER 60 SERIES BUSH TO BE USED WHEN FITTING THIS PART NUMBER TO PATROL/MAVERIC TRAYBACK						
** NEEDS LONG TRAVEL SHOCK ABSORBERS						
+ THIS PART NUMBER IS A TOP STAGE ONLY TO BOLT TO EXISTING 2ND STAGE						
HOLDEN						
RODEO SINGLE CAB 8/88 - 02/03					HOL-203*	
RODEO RA 03 - ON					HOL-206 ZZ	HOL-206HD ZZ
COLORADO 2008-2011					HOL-206 ZZ	HOL-206HD ZZ
COLORADO 2012					HOL-207	
COLORADO 2012					HOL-207TS+	HOL-207HDTS+
* LONGER U/BOLTS REQUIRED - UB-453/1						
ISUZU						
DMAX 2008-2011					HOL-206 ZZ	HOL-206HD ZZ
DMAX 2012					HOL-207*	
DMAX 2012 *TOP STAGE ONLY*					HOL-207TS+ *	HOL-207HDTS+ *
+ THIS PART NUMBER IS A TOP STAGE ONLY TO BOLT TO EXISTING 2ND STAGE						
* REQUIRES BRAKE BRACKET KIT P/NUMBER TDSK-021						
JEEP						
CHEROKEE XJ	REFER COIL SPRINGS					JEEP-03*
* LONGER U/BOLTS REQUIRED - UB-04						
MAZDA						
BRAVO 92 - ON						MAZ-005
BT-50 2007 TO 2011					MAZ-009	MAZ-009HD
BT-50 2012 ON					MAZ-010**	MAZ-010HD**
BT-50 2012 ON *TOP STAGE ONLY*					MAZ-010ST** +	MAZ-010HDTS** +

4WD LEAF SPRINGS

MAKE AND MODEL	FRONT			REAR		
	STD Height	Raised Height	EHD Height	STD Height	Raised Height	EHD Raised
** NEEDS LONG TRAVEL SHOCK ABSORBERS						
+ THIS PART NUMBER IS A TOP STAGE ONLY TO BOLT TO EXISTING 2ND STAGE						
MITSUBISHI						
CHALLENGER PA 3/98 TO 8/00	ADJUSTABLE TORSION BAR				MIT-021	
TRITON ML 4WD					MIT-023SP	MIT-023SPHD**
** MUST HAVE 500KG+ CONSTANT LOAD OTHERWISE DRIVE TRAIN SHUDDER COULD BE EXPERIENCED						
NISSAN						
NAVARA D21 D22 SER 1&2 MY02 - SINGLE CAB	ADJUSTABLE TORSION BAR				NIS-013	NIS-014***
NAVARA D21 D22 SER 1&2 MY02 - DUAL CAB	ADJUSTABLE TORSION BAR			NIS-013	NIS-014***	
NAVARA D40	REFER COIL SPRINGS				NIS-032 **	NIS-032HD ** *
NAVARA D40 EHD OPTION	REFER COIL SPRINGS					NIS-032EHD ** *
PATROL MQ 160 80-83 SWB (STEEL BUSH FR OF FR LOWER)		NIS-011/SWB*			NIS-002	NIS-001*
PATROL MQ 160 80-83 LWB (STEEL BUSH FR OF FR LOWER)		NIS-011*			NIS-005*	NIS-001*
PATROL MQ 160 80-83 T/BACK 4.0 P & 3.3 D (STEEL BUSH FR OF FR LOWER)		NIS-011*			NIS-001*	NIS-006*
PATROL MQ 160 80-83 SWB (RUBBER BUSH FR OF FR LOWER)		NIS-012/SWB*			NIS-002	NIS-001*
PATROL MQ 160 80-83 LWB (RUBBER BUSH FR OF FR LOWER)		NIS-012*			NIS-005*	NIS-001*
PATROL MQ 160 80-83 T/BACK 4.0 P & 3.3 D (RUBBER BUSH FR OF FR LOWER)		NIS-012*			NIS-001*	NIS-006*
PATROL GQ GU GUII T/BACK (LEAF SPRING)		TOY-059+	TOY-060+			NIS-016#
*NEEDS LONG TRAVEL SHOCK ABSORBERS **LONGER U/BOLTS REQUIRED - UB/453/2 ***LONGER U/BOLTS REQUIRED - UB-700						
+35MM LANDCRUISER 60 SERIES BUSH TO BE USED WHEN FITTING THIS PART NUMBER TO PATROL/MAVERIC TRAYBACK						
# REQUIRES TOYOTA LANDCRUISER 75 SERIES FRONT EYE BUSHES						
SUZUKI						
SIERRA SJ413,50,51,70 SWB 1300	SUZ-001	SUZ-002*	SUZ-004*	SUZ-003	SUZ-006*	SUZ-007*
SIERRA SJ413,50,51,70 LWB 1300	SUZ-001	SUZ-002*	SUZ-004*	SUZ-006	SUZ-008*	SUZ-009*
SIERRA SJ413,50,51,70 T/BACK 1300	SUZ-001	SUZ-002*	SUZ-004*	SUZ-007	SUZ-009*	SUZ-011*
* NEEDS LONG TRAVEL SHOCK ABSORBERS						
TOYOTA						
HILUX RN36,46,105,YN65,67 PETROL (LEAF FRONT)	TOY-202	TOY-203*	TOY-502*		TOY-017	TOY-048**
HILUX LN36,46,65,67 DIESEL (LEAF FRONT)	TOY-500	TOY-502*	TOY-503*		TOY-017	TOY-048**
HILUX LN106 DIESEL (LEAF FRONT)	TOY-500	TOY-502*	TOY-503*		TOY-017	TOY-048**
** LONGER U/BOLTS REQUIRED UB*453/2 NOTE: FOR TOY-500 SERIES LEAF SPRINGS, FLAT TOP DRIVERS SIDE U/BOLT REQUIRED UB-449/3						
HILUX SINGLE STAGE EXTRA HIGH REAR (LEAF FRONT)						TOY-201
HILUX RN110, LN111, A4 LN167 (INDEPENDENT FRONT)	ADJUSTABLE TORSION BAR				TOY-049	TOY-208
HILUX SR5 RN110, LN107, 111 (INDEPENDENT FRONT)	ADJUSTABLE TORSION BAR				TOY-041	TOY-049
HILUX 2005	REFER COIL SPRINGS				TOY-092	TOY-092HD
4 RUNNER YN60 PETROL (LEAF FRONT)	TOY-202	TOY-203*			TOY-017	TOY-207
4 RUNNER YN60 DIESEL (LEAF FRONT)	TOY-203	TOY-502*	TOY-503*		TOY-017	TOY-207
4 RUNNER YN63, LN61 (INDEPENDENT FRONT)	ADJUSTABLE TORSION BAR				TOY-017	TOY-207
LANDCRUISER SWB 40-42 SERIES PRE 1980 (25MM EYES)		TOY-209*	TOY-210*		TOY-010*	TOY-052*

4WD LEAF SPRINGS

MAKE AND MODEL	FRONT			REAR		
	STD Height	Raised Height	EHD Height	STD Height	Raised Height	EHD Raised
LANDCRUISER SWB 40-42 SERIES 1980 - ON (35MM EYES)		TOY-211*	TOY-212*		TOY-001*	TOY-054*
LANDCRUISER LWB 45-47 SERIES PRE 1980 (25MM EYES)		TOY-050*	TOY-051*		TOY-022	TOY-055
LANDCRUISER LWB 45-47 SERIES 1980 - ON (35MM EYES)		TOY-015*	TOY-053*		TOY-016	TOY-056
LANDCRUISER 60 SERIES PETROL	TOY-213	TOY-059*	TOY-060*	TOY-214	TOY-024	TOY-062** *
LANDCRUISER 60 SERIES DIESEL	TOY-059	TOY-023*	TOY-061*	TOY-214	TOY-024	TOY-062** *
LANDCRUISER 60 SERIES SINGLE STAGE EHD OPTION						TOY-024HD
LANDCRUISER 73/74 SERIES MWB			TOY-031			TOY-214
LANDCRUISER 75 SERIES		TOY-031*	TOY-065*		TOY-025	TOY-066** *
LANDCRUISER 75 SERIES EHD OPTION						TOY-066HD** *
LANDCRUISER 76 SERIES		REFER COIL SPRINGS			TOY-093	TOY-093HD
LANDCRUISER 76 SERIES EHD OPTION		REFER COIL SPRINGS				TOY-093EHD
LANDCRUISER 78/79 SERIES		REFER COIL SPRINGS			TOY-091	TOY-091HD
*LONG TRAVEL SHOCK ABSORBERS MUST BE USED WITH THIS PART NUMBER **THIS IS A TWO STAGE SPRING. LONGER U/BOLTS REQUIRED						
VOLKSWAGON						
AMOROK *MUST USE KIT-183K BUSH KIT					VOL-002 ZZ	

[BACK](#)

[BACK](#)

[BACK](#)