

4WD LEAF SPRINGS

MAKE & MODEL	FRONT			REAR		
	STD HEIGHT	RAISED HEIGHT	EHD RAISED	STD HEIGHT	RAISED HEIGHT	EHD RAISED
DAIHATSU						
FEROZA	ADJUSTABLE TORSION BAR				DIA-004*	DIA-002*
ROCKY SWB F70, LWB F75 DIESEL		DIA-001*	DIA-017*		DIA-004*	DIA-002*
ROCKY SWB F80, LWB F85 PETROL		DIA-003*	DIA-001*		DIA-004*	DIA-002*
ROCKY T/BACK F77 DIESEL		DIA-001*	DIA-017*		DIA-007*	DIA-008*
ROCKY T/BACK F87 PETROL		DIA-003*	DIA-001*		DIA-007*	DIA-008*
* EXCEPT WIDE TRACK						
FORD						
COURIER PC PD PG PH						MAZ-005
EXPLORER UN UP UQ US					FOR-028	
MAVERICK TRAYBACK		TOY-059*	TOY-060*		NIS-015	NIS-016**
RANGER					MAZ-009	MAZ 009HD
* 35mm L/CRUISER 60 SERIES BUSH TO BE USED WHEN FITTING THIS PART NUMBER TO PATROL/MAVERICK TRAYBACK						
** NEEDS LONG TRAVEL SHOCK ABSORBERS						
HOLDEN						
RODEO SINGLE CAB 8/88 - 02/03					HOL-203*	
RODEO RA 03 ON / COLORADO 08 ON					HOL-206 Z	HOL-206HD Z
* LONGER U/BOLTS REQUIRED UB-453/1						
JEEP						
CHEROKEE XJ		REFER COIL SPRINGS				JEEP-03*
* LONGER U/BOLTS REQUIRED UB-04						
LANDROVER						
SWB		LAN-003			LAN-002	
LWB		LAN-004			LAN-001	
MAZDA						
BRAVO 92 ON						MAZ-005
BT-50					MAZ-009	MAZ-009HD
MITSUBISHI						
CHALLENGER PA 3/98-8/00		ADJUSTABLE TORSION BAR				MIT-021
TRITON ML 4WD					MIT-023SP	MIT-023SPHD
NISSAN						
NAVARA D21 D22 SER 1&2 MY02 - SINGLE CAB		ADJUSTABLE TORSION BAR				NIS-013
NAVARA D21 D22 SER 1&2 MY02 - DUAL CAB		ADJUSTABLE TORSION BAR			NIS-013	NIS-014***
NAVARA D40		REFER COIL SPRINGS				NIS-032**
NAVARA D40 EHD OPTION		REFER COIL SPRINGS				NIS-032EHD***
PATROL MQ 160 80-83 SWB		NIS-011/SWB*				NIS-002
(Steel bush Fr of Fr Lower)						NIS-001*
PATROL MQ 160 80-83 LWB		NIS-011*				NIS-005*
(Steel bush Fr of Fr Lower)						NIS-001*
PATROL MQ 160 80-83 T/BACK 4.0 Petrol 3.3 Diesel		NIS-011*				NIS-001*
(Steel bush Fr of Fr Lower)						NIS-006*
PATROL MQ 160 83-86 SWB		NIS-012/SWB*				NIS-002
(Rubber bush Fr of Fr Lower)						NIS-001*
PATROL MQ 160 83-86 LWB		NIS-012*				NIS-005*
(Rubber bush Fr of Fr Lower)						NIS-001*
PATROL MQ 160 83-86 T/BACK 4.0 Petrol 3.3 Diesel		NIS-012*				NIS-001*
(Rubber bush Fr of Fr Lower)						NIS-006*
PATROL GQ GU GUII T/BACK (LEAF SPRING)		TOY-059+	TOY-060+			NIS-016*#
** LONGER U/BOLT REQUIRED: UB-453/2						
*** LONGER U/BOLT REQUIRED : UB-700						
+ 35mm LAND CRUISER 60 SERIES BUSH TO BE USED WHEN FITTING THIS PART NUMBER TO PATROL/MAVERICK TRAYBACK						
* NEEDS LONG TRAVEL SHOCK ABSORBERS						
# REQUIRES TOYOTA LANDCRUISER 75 SERIES FRONT EYE BUSHES						
SUZUKI						
SIERRA SJ413, 50, 51, 70, SWB 1300	SUZ-001	SUZ-002*	SUZ-004*	SUZ-003	SUZ-006*	SUZ-007*
SIERRA SJ413, 50, 51, 70, LWB 1300	SUZ-001	SUZ-002*	SUZ-004*	SUZ-006	SUZ-008*	SUZ-009*
SIERRA SJ413, 50, 51, 70, T/BACK 1300	SUZ-001	SUZ-002*	SUZ-004*	SUZ-007	SUZ-009*	SUZ-011*

4WD LEAF SPRINGS

MAKE & MODEL	FRONT			REAR		
	STD HEIGHT	RAISED HEIGHT	EHD RAISED	STD HEIGHT	RAISED HEIGHT	EHD RAISED

* NEEDS LONG TRAVEL SHOCK ABSORBERS

TOYOTA						
HILUX RN36,46,105,YN65,67 PETROL (Leaf Frt)	TOY-202	TOY-203*	TOY-502*		TOY-017	TOY-048**
HILUX LN36, 46, 65, 67 DIESEL (Leaf Frt)	TOY-203	TOY-502*			TOY-017	TOY-048**
HILUX LN106 DIESEL (Leaf Frt)	TOY-500	TOY-502*			TOY-017	TOY-048**
** NOTE LONGER U/BOLTS REQUIRED UB-453/2						
NOTE: FOR TOY-500 SERIES FLAT TOP D/SIDE U/BOLT REQUIRED UB-449/3						
HILUX (Leaf Frt) Single Stage Extra High Rear						TOY-201
HILUX RN110, LN111,A4 LN167(Ind Frt)	ADJUSTABLE TORSION BAR				TOY-049	TOY-208
HILUX SR5 RN110 LN107, 111 (Ind Frt)		"			TOY-041	TOY-049
HILUX 05					TOY-092	TOY-092HD
4 RUNNER YN60 PETROL (Leaf Frt)	TOY-202	TOY-203*			TOY-017	TOY-207
4 RUNNER LN60 DIESEL (Leaf Frt)	TOY-203	TOY-502*			TOY-017	TOY-207
4 RUNNER YN63 LN61 (Ind Frt)	ADJUSTABLE TORSION BAR				TOY-017	TOY-207
L/CRUISER SWB 40-42 SERIES PRE 1980(25MM EYES)		TOY-209*	TOY-210*		TOY-010*	TOY-052*
L/CRUISER SWB 40-42 SERIES 1980 ON(35MM EYES)		TOY-211*	TOY-212*		TOY-001*	TOY-054*
L/CRUISER LWB 45-47 SERIES PRE 1980 (25MM EYES)		TOY-050*	TOY-051*		TOY-022	TOY-055
L/CRUISER LWB 45-47 SERIES 1980 ON (35MM EYES)		TOY-015*	TOY-053*		TOY-016	TOY-056
L/CRUISER 60 SERIES PETROL	TOY-213	TOY-059*	TOY-060*	TOY-214	TOY-024	TOY-062** *
L/CRUISER 60 SERIES DIESEL	TOY-059	TOY-023*	TOY-061*	TOY-214	TOY-024	TOY-062** *
L/CRUISER 60 SERIES SINGLE STAGE EHD OPTION						TOY-024HD
L/CRUISER 73/74 SERIES MWB			TOY-031			TOY-214
L/CRUISER 75 SERIES		TOY-031*	TOY-065*		TOY-025	TOY-066** *
L/CRUISER 75 SERIES EHD OPTION						TOY-066HD** *
L/CRUISER 76 SERIES	REFER COIL SPRINGS LISTINGS				TOY-093	TOY-093HD
L/CRUISER 76 SERIES EHD OPTION	REFER COIL SPRINGS LISTINGS					TOY-093EHD
L/CRUISER 78/79 SERIES	REFER COIL SPRINGS LISTINGS				TOY-090	TOY-091
L/CRUISER 78/79 SERIES EHD OPTION		"				TOY-091HD** *
* LONG TRAVEL SHOCK ABSORBERS MUST BE USED WITH THIS PART NUMBER						
** THIS IS A TWO STAGE SPRING. LONGER U/BOLTS REQUIRED						